





LANDING PLATE FIXING INSTRUCTIONS

PLAN VIEW



SECTION VIEW



The Angle Brackets are supplied fixed to the landing, so they can be drilled and bolted to the finished floor joist

British Spirals & Castings

Peak Building, Eccles Rd, Chapel-en-le-Frith, High Peak, SK23 9RG

T +44(0)1663 750716 **E** sales@britishsc.co.uk **www.britishsc.co.uk**

A trading division of Harding Sales Ltd. Registered Office: Gorsty Low Farm, The Wash, Chapel-en-le-Frith, SK23 0QL. Company Registration Number: 7550371

A FOUNDING MEMBER OF
The Spiral Manufacturers Association